

Milwaukee Packout Mount Install Instructions:



Please read these notes before installing

- 2nd Gen Packout Mount Does **NOT** use Middle Anchors
- **Pro S Ultimate** – If using with a Yeti 35, you may need to use a grinder to take a little plastic off the Packout to allow for more clearance for the Yeti to open. The Pro S Ultimate has bigger speakers than other models. (See pictures on the last page)
- **Pro R (Newer Models)** – You may need to remove the plastics next to the air intakes to get the Packout Mount to sit properly. These can be re-installed once you set the packout mount.
- When twisting on the anchor tops, be sure “RUS OFFROAD” is facing up. This prevents the nut from coming loose. You need to hold the bottom of the anchors when tightening to prevent it from spinning. The anchors include a locknut and can require a little force to tighten fully.
- The 2nd Generation Packout Mount has slots instead of holes. Once you get it installed, install the Packout and Cooler (if you are using one) and slide the mount forwards/backwards for the perfect location. Tightened down anchors fully once adjusted.



1. Remove the 2 factory T40 bolts.
2. Push the anchors with the 2in bolts up from the bottom. On some machines, the roll cage may block part of the anchors from entering completely. Rotate the anchor so that it can enter the hole completely without binding on roll cage.

NOTE: The 2nd Generation Packout mount does not use these anchors.
3. Push the anchors with the 5in bolts up from the bottom. Once the anchor and bolt are installed, slide the 3in spacer onto each rearward bolt. This will help support the packout.
4. Install the anchor tops by spinning them onto the bolts. **DO NOT USE POWERTOOLS.** Tighten by hand only. You will need to hold the bottom of the anchor to keep it from spinning while tightening.
5. Reinstall 2 factory T40 bolts plus the included washers.

MISC:

Pro S Ultimate ONLY – If using with a Yeti 35, you may need to use a grinder to take a little plastic off of the corner on the Packout to allow for more clearance for the Yeti to open more. The Pro S Ultimate has bigger speakers than other models.

